





GW1N-4K-QFN88




*Power section (Please refer to the manual for power supply range)




*Configuration reset section (low level)




*Configuration completed detection section



*Configuration mode signal selection section



JTAG mode selection signal section



*JTAG download section

GW2A-18K-PBGA256

