










\*Configurable detection section










THIS DOWNLOAD SECTION









\*Power section (Please refer to the manual for power supply range)






GW1N-UV2-LQ144F1



\*Power section (Please refer to the manual for power supply range)



READY << R104 4.7K VCC00

\*Configurable detection section

RECONFIG\_N << R105 4.7K VCC00

\*Configuration reset section

JTAGSEL\_N >> R106 33

JTAG mode selection signal section

DONE >> R107 4.7K VCC00

\*Configuration completed detection section

