




























GW1N-LV2-LQ144X2






































































GW1N-LV2-MG132X2

















```
*Configuration reset section
```




JTAG mode selection signal section



*Configuration mode signal selection



*Power section (Please refer to the manual for power supply range)



*JTAG download section

